

HC6-800 规格书 Specifications

电气参数 Ratings:

◇额定工作电压

Rated Operational Voltage: 1000V

◇额定工作电流

Rated Current: 630, 800A

◇额定绝缘电压

Rated Insulation Voltage: 1000V

◇额定冲击耐受电压

Rated Impulse Voltage: 8kV

◇额定接通能力

Rated Making Capacity: 10×le (AC-3), 12×le (AC-4)

◇额定分断能力

Rated Breaking Capacity: 8×le (AC-3), 10×le (AC-4)

◇极数

Number of Poles: 3P, 4P

认证/标准 Approvals/Standard:

 \diamond CCC



产品特征 Features&Benefits:

模块化设计,产品结构紧凑

Modular design, compact product structure

操作性能安全可靠

Safe and reliable operation performance

特殊的触点工艺确保连续可靠的传导

The special process of the contacts ensures continuous and reliable conduction

安装方便, 无需工具安装附件

Convenient installation without tools to install and remove accessories

多种接线端子可供选择,接下能力范围广

A variety of connection wire terminal options, wide range of wiring capabilities

更好的抗冲击性和抗震性能

Better impact resistance and seismic performance

防尘性能好, 可选配防尘配件

Dustproof performance, optional dustproof accessories can be added

低功耗线圈

Low power consumption coil

产品型号说明 Product Model:										
	HC6	-800	N	4	220V	50/60Hz				
公司代码 Company Code										
额定电流 Rated Current	630=630A 800=800A									
特殊功能 Special Function	N: 水平联锁 Horiz L: 垂直联锁 Vertio Nil: 非可逆接触器									
极数 Poles	Nil: 3P 4: 4P									
控制回路电压 Control Circuit Voltage	24V 48V 110V 220V 380V 415V									
频率 Frequency	50Hz 50/60Hz 直流 DC									



特性参数 CHARACTERIS	TIC PARAMETE	RS						
产品型号 Product Model			HC6-630	HC6-800				
约定自由空气发热电流 Conventional Free Air Thermal Current (Ith)	≤140°F (≤60°C)	А	1000	1000				
极数 Poles			3	3				
额定绝缘电压 Rated Insulation \		V	1000					
额定冲击耐受电压 Rated Impuls		kV	8 接通电流 Marking Current: 10×le (AC-3), 12×le (AC-4)					
额定接通能力 Rated Making Ca 额定分断能力 Rated Breaking C	•			10×le (AC-3), 12×le (AC-4) : 8×le (AC-3), 10×le (AC-4)				
一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一	1	_						
Electrical Durability ×10 ⁴	AC-3	Ops	20	15				
机械寿命 Mechanical Durability		Ops	100	100				
最大操作频率 Maximum Operat	ion Frequency	Ops/h	300	300				
每极平均阻抗 (Ith及50Hz下) Average Impedance Per Pole at	Ith&50Hz	mΩ	0.12	0.12				
相匹配的熔断器 Matching Fuse		l .	RT16-3	RT16-4				
熔断器电流 Fuse Current	71	Α	630	800				
自带辅助触头数量 Auxiliary Cor	tact Composition	II.	-	-				
安装位置 Installation Position								
外壳防护等级 Protection Degree			IP	00				
抗冲击能力 Impact Resistance	打开 Open	g	9	9				
1/2正弦波 Sine Wave =11ms	闭合 Close	g	15	15				
抗震能力	打开 Open	g	2	<u>2</u> 4				
Seismic Performance 重量 Weight	闭合 Close	g kg	4 17.4	17.4				
AC-1		l kg	17.4	17.4				
额定工作电流	≤104°F (≤40°C)	Α	1000	1000				
Rated Operational Current (le)	` ,							
额定工作功率 Rated Operational Power (Pe)	380/415V 660/690V	kW kW	600 1000	600 1000				
AC-3	000/0907	I KVV	1000	1000				
额定工作电流	380/400V	Α	630	800				
Rated Operational Current (le)	660/690V	Α	560	650				
	220/240V 380/400V	kW kW	200 335	250 450				
ما مد ما	415V	kW	375	450 450				
额定工作功率 Rated Operational Power (Pe)	440V	kW	400	450				
Tated Operational Fower (Fe)	500V	kW	400	450				
	660/690V 1000V	kW kW	450 450	475 450				
AC-4	10007	NVV	430	430				
	230V	Α	230	230				
额定工作电流 Rated Operational Current (le)	380/400V	Α	225	242				
· · · · · · · · · · · · · · · · · · ·	660/690V 230V	A kW	200	215 75				
额定工作功率	380/400V	kW	75 110	132				
Rated Operational Power (Pe)	660/690V	kW	185	200				
. ,	100V	kW	150	200				
	10s	٨	5050	5500				
短时耐受电流	30s	A	4600	4600				
Short-Time Withstand Current	1min	Α	3600	3600				
≤104°F (≤40°C)	3min	Α	2600	2600				
	10min	Α	1700	1700				

V.02




特性参数 CH	IARACTERIS	TIC PARAMETE	RS					
产品型号 Produc	t Model			HC6-630	HC6-800			
UL								
1P 110-120V 220-240V 200-200V		HP HP	<i> </i>	<i>I</i>				
Rated Power of N 50/60Hz	Motor 3P	200-208V 220-240V	HP HP	/ 250	300			
		440-480V 550-600V	HP HP	500 600	600 700			
控制回路特性 Co	ontrol Circuit C	haracteristic						
控制回路电压 Control Circuit Vo	oltage		V	AC:24/48/110/220/380/415V; DC:24/48/110/220V				
电压范围 Voltage Range	I and A I be	吸合 Pick-up 释放 Drop-out			10%) Us DC: (10%-60%) Us			
交流单线圈 AC Single Coil 50Hz		er Consumption	VA		l			
		ver Consumption	VA		l			
	吸合延时 Pick-up Dela	ay	ms	I				
	释放延时 Drop-out De	elay	ms	1				
		er Consumption	VA	1730				
交流单线圈 AC Double Coil	保持 Sealing Pow	er Consumption	VA	25				
50/60Hz	吸合延时 Pick-up Dela	ау	ms	40-80				
	释放延时 Drop-out De	elay	ms	100-200				
		er Consumption	W	1920				
直流线圈 DC Coil	保持 Sealing Pow	er Consumption	W	12	2.5			
	吸合延时 Pick-up Dela	ay	ms	60	-70			
	释放延时 Drop-out De	elay	ms	40-50				
接线能力 Conne	ctions							
主回路 Main Circuit	电缆 Cable		mm²	60*5*2				
	扭矩 Tighte	ning Torque	N·m	58				
控制回路 Control Circuit	软线 Flexible	软线 Flexible 1根 Piece		1-2.5				
	硬线 Solid	1根 Piece	mm²	1-4				
		olid/Stranded	AWG	16-14				
	扭矩 Tighte	ning Torque	N·m	1	.2			

https://www.hiitio.com



外形及安装尺寸 Ourline and Installations mm [inch]:



HC6		В	c	4	f	h		G	u	ф1	Х	1
псо	a	Γ	3	Ψ	ı	D	C	G	П		≤500V	>500V
630F	309[12.17]	80[3.15]	40[1.57]	M12	201[7.91]	304[11.97]	255[10.04]	180[7.09]	180[7.09]	10.5[0.41]	20[0.79]	30[1.18]
800F	309[12.17]	80[3.15]	40[1.57]	M12	201[7.91]	304[11.97]	255[10.04]	180[7.09]	180[7.09]	10.5[0.41]	20[0.79]	30[1.18]

f: 取出线圈的最小距离 Minimum distance to taking out coil;

X1: 最小电气间隙(飞弧距离) minimum electrical clearance (arcing distance).

安装使用及维护 Precautions for Use:

- 1.安装前首先检查实际使用场合是否符合接触器的用途与适用范围、技术参数及其正常工作条件和安装条件等。 Before installation, first check whether the actual use situation conforms to the purpose and scope of application, technical parameters, normal working conditions and installation conditions of the contactor.
- 2.安装时,将接触器的止动件向下拉,把接触器置于安装轨上,再将止动件向上推使接触器固定在安装轨上,不得松动、脱落。需要拆卸接触时,将止动件拉下便可轻松取下。

During installation, pull down the stopper of the contactor, place the contactor on the mounting rail, and then push the stopper upward to fix the contactor on the mounting rail without loosening or falling off. When the contact needs to be removed, the stopper can be easily removed by pulling it down.

- 3.接触器接线时应将导线伸入接线孔中,然后拧紧接线螺钉,使导线不得松动、拔出。裸露铜线头不能露在接线端外。 When the contactor is connected, the wire shall be inserted into the connection hole, and then the connection screw shall be tightened to prevent the wire from loosening and pulling out. The exposed copper wire head shall not be exposed outside the terminal.
- 4.接触器在接线时不得猛拧接线螺钉,在拧紧和拧松螺钉时所用螺丝刀应适当,避免使用气动工具打滑螺钉。 When connecting the contactor, it is not allowed to screw the connecting screw violently. When tightening and loosening the screw, the screwdriver shall be appropriate to avoid slipping the screw with pneumatic tools.
- 5.检查接线正确无误后,应在主触头不带电的情况下,先使线圈通电分合数次,检查产品动作是否可靠,然后才能投入使用。 After checking whether the wiring is correct, when the main contact is not charged, the coil shall be powered on and off for several times to check whether the product action is reliable, and then it can be put into use.
- 6.当接触器间、接触器与断路器间紧靠安装时,需安装间隔件以利于散热; 当配电箱内温度超过+60°C时,接触器需要降容使用。 When contactors, contactors and circuit breakers are installed close to each other, spacers shall be installed to facilitate heat dissipation; When the temperature in the distribution box exceeds + 60°C, the contactor needs to be reduced in capacity.
- 7.接触器在使用期中,应定期检查接线螺钉的松紧情况,如出现松脱应及时将其拧紧;定期清除外壳表面的尘埃,保持外壳良好的绝缘性;在 用中如出现较大的噪音或外壳绝缘失效等情况,应及时更换新的产品;按照产品工作频率和使用时间来计算,当产品的工作次数达到(或接近产品的使用寿命时,应及时更换新的产品。

During the service life of the contactor, the tightness of the connecting screw shall be checked regularly, and in case of looseness, it shall be tightened in time; Regularly remove the dust on the surface of the shell to maintain good insulation of the shell; In case of large noise or shell insulation failure during use, new products shall be replaced in time; According to the working frequency and service time of the product, when the working frequency of the product reaches (or approaches) the service life of the product, the new product shall be replaced in time.

8.接触器的保质储存期为自出厂之日(见产品合格证或生产批号)起24个月,储存温度为-25°C~+60°C,且不得受雨雪侵袭和阳光直射。产品存期的产品必须重新检查。如因储存不当或超过储存期未经检查就使用儿出现质量问题,按有关质量法规处理。

The shelf life of the contactor is 24 months from the date of delivery (see the product certificate or production batch number). The storage temperature is $-25^{\circ}\text{C} \sim +60^{\circ}\text{C}$, and it shall not be affected by rain and snow and direct sunlight. Products in the storage period must be rechecked. In case of quality problems caused by improper storage or use without inspection beyond the storage period, it shall be handled according to relevant quality regulations.